

# Impact of stabilization environment and heating rates on P84 co-polyimide/nanocrystalline cellulose carbon membrane for hydrogen enrichment

*N. Sazali<sup>a,b,c</sup>, W.N.W. Salleh<sup>a,b,\*</sup>, A.F. Ismail<sup>a,b,\*\*</sup>, K. Kadirgama<sup>c</sup>,  
F.E.C. Othman<sup>a,b</sup>, N.H. Ismail<sup>a,b</sup>*

<sup>a</sup>Advanced Membrane Technology Research Centre (AMTEC), Universiti Teknologi Malaysia, Skudai, 81310, Johor Darul Takzim, Malaysia

<sup>b</sup>Faculty of Chemical and Energy Engineering (FCEE), Universiti Teknologi Malaysia, Skudai, 81310, Johor Darul Takzim, Malaysia

<sup>c</sup>Faculty of Mechanical Engineering, Universiti Malaysia Pahang, Pekan Pahang Darul Makmur, 26600, Malaysia

## Abstract

These past few decades, the separation of various gas mixtures problems in order to obtain high purity gases can be overcome by the introduction of membrane-based technology. This current research was focusing on the development of tubular carbon membranes (TCMs) from polymeric precursors for the separation of [hydrogen](#) and [nitrogen](#). The [fabrication](#) of TCMs involved the [dip coating](#) technique and was using P84 co-polyimide as the main precursor by blending of nanocrystalline cellulose (NCC) as an additive. It was believed a slight adjustment on [time, temperature](#), or environment of the [carbonization](#) protocol for the commercially available PI/NCC membranes can alter the [final properties](#) of the carbons produced. The modifications on the carbonization parameters such as stabilization conditions and heating rates during fabrication of PI/NCC-based carbon membranes could also affect their gas [separation performance](#). A large variety of TCMs for [gas separation](#) have been developed by simple carbonization of a PI/NCC deposited on a ceramic tubular support. Herein, in this study, the effect of different heating rates (1, 3, 5, and 7 °C/min) and stabilization environment (Argon, Nitrogen, and Helium) were investigated for all resultant TCMs. As a result, it was observed that stabilization under [Argon](#) environment with [heating rate of](#) 3 °C/min produced carbon membranes with the best H<sub>2</sub>/N<sub>2</sub> separation and the highest selectivity of 434.68 ± 1.39, respectively.

**Keywords:** Heating rates; Stabilization environment; P84 co-polyimide; Nanocrystalline cellulose (NCC); Hydrogen separation