

## One-step production of pyrene-1-boronic acid functionalized graphene for dopamine detection

*Ellie Yi Lih Teo<sup>a,b</sup>, Gomaa A. M. Ali<sup>a,c</sup>, H. Algarni<sup>d,e</sup>, Wilairat Cheewasedtham<sup>f</sup>, Thitima Rujiralai<sup>f,g</sup>, Kwok Feng Chong<sup>a</sup>*

<sup>a</sup> Faculty of Industrial Sciences & Technology, Universiti Malaysia Pahang, Lebuhraya Tun Razak, 26300 Gambang, Kuantan, Pahang, Malaysia

<sup>b</sup> R&D Technologies, NGLTech Sdn. Bhd., Suite 8-3, Wisma UOA II, No. 21, Jalan Pinang, 50450, Kuala Lumpur, Malaysia

<sup>c</sup> Chemistry Department, Faculty of Science, Al-Azhar University, 71524, Assiut, Egypt

<sup>d</sup> Department of Physics, Faculty of Sciences, King Khalid University, P. O. Box 9004, Abha, Saudi Arabia

<sup>e</sup> Research Center for Advanced Materials Science (RCAMS), King Khalid University, Abha 61413, P. O. Box 9004, Saudi Arabia

<sup>f</sup> Analytical Chemistry and Environment Research Unit, Division of Chemistry, Department of Science, Faculty of Science and Technology, Prince of Songkla University, Pattani, 94000, Thailand

<sup>g</sup> Department of Chemistry and Center of Excellence for Innovation in Chemistry, Faculty of Science, Prince of Songkla University, Hat Yai, Songkhla, 90112, Thailand

### ABSTRACT

A facile molecular wedging method is used to exfoliate graphite flakes into graphene sheets, with concurrent functionalization to form pyrene-1-boronic acid functionalized graphene (PBA/G). Different techniques are used to characterize the prepared materials such as field emission scanning electron microscope, energy dispersive X-ray analyzer, Raman, Fourier transformed infrared spectroscopy and fluorescence spectroscopy to evaluate their structural and morphological characteristics. The intercalation of PBA into graphite sheets, followed by exfoliation can be observed under the electron microscope. Elemental analyses show that the PBA acts more than intercalant, it is functionalized onto the graphene sheets upon exfoliation to form PBA/G. Raman analysis indicates PBA/G has a lower number of graphene layers as a result of successful exfoliation by PBA. Electrochemical impedance studies show that the PBA/G possesses high affinity for dopamine through the diol groups interaction, which renders it to have enhanced detection for dopamine.

### KEYWORDS

Functionalized grapheme; Sensor; Dopamine; Pyrene-1-boronic acid; Electrochemical impedance

## **ACKNOWLEDGEMENTS**

The authors would like to acknowledge the funding from the Ministry of Education Malaysia in the form of FRGS [RDU170113 : FRGS/1/2017/STG07/UMP/01/1], Universiti Malaysia Pahang grant RDU170357 and King Khalid University, the Ministry of Education in Saudi Arabia for supporting this research through grant (RCAMS/KKU/002-18) under research center for advanced material science.